



即時輸出表示: TN132-TN111-HEATSINK

X: X+/-0.1
X: XX+/-0.01
X: XXX+/-0.001
ANG: +/-0.5