



即時輸出表示: TN132-TN86-HEATSINK

X, X+/-0.1
X, XX+/-0.01
X, XXX+/-0.001
ANG. +/-0.5